




**PREPARATION**




Acceptance of the delivery. Check the seals and the correctness of the delivery.




Storage.




Loading and securing.



Prepare protective clothing.




Inspect the machine.




Read the documentation of PUREX NG.


**SET-UP**




Attached the lid with 3 holes and an agitator.




Remove the previously used system from the machine circuit. Pay attention to labels on drums.



Install the pump, agitator and recirculation system.




Heat and agitate the material until it reaches required temperature. Keep an eye on temperature during spraying.



Remember to set the correct operating temperature for the ambient conditions. Start only if you have reached the recommended temperature range.

**EXECUTION**

**12**




POLY 30°C      ISO 30°C

**TEMPERATURE**  
POLY  
ISO  
HOSES      50-55°C

Set the correct temperature for spraying.  
Keep mixing.

**13**



**85 -110 bar**


Set the correct operating pressure.

**14**



Check the condition of the substrate – temperature, humidity, correctness of execution.


**15**



✓ COLOUR  
✓ STRUCTURE


Perform a test spray to verify proper processing.

**16**



Keep checking the thickness of the layer as you work.

**17**



Remember to keep an eye on the machine parameters and the raw material temperature.


**FINISHING**

**18**



Turn off the device according to the manufacturer's instructions and secure the spray gun.

**19**




After work, ventilate the room where spraying was carried out (at least 24 hours).

**20**



Upon acceptance of the work, remember to issue an Applicator's Declaration and leave a set of documents for the system.

**21**



Rest after the work you've done.

**BE A PROFESSIONAL IN INSULATION**