




PREPARATION




Acceptance of the delivery. Check the seals and the correctness of the delivery.




Storage.




Loading and securing.



Prepare protective clothing.




Inspect the machine.




Read the documentation of PUREX NG.


SET-UP




Fit the recirculation system and remove previously used system from the machine circuit. Mount the pump.



Recirculation should be carried out within the specified temperature range.



Keep an eye on the temperature during spraying.



Remember to set the correct operating temperature for the ambient conditions. Start only if you have reached the recommended temperature range.

EXECUTION

11

TEMPERATURE

POLY ISO HOSES 40-50°C

POLY 20-35°C ISO 20-35°C

Set the correct temperature for spraying.

12

85 -110 bar

Set the correct operating pressure.

13

Check the condition of the substrate – temperature, humidity, correctness of execution.

14

✓ COLOUR

✓ STRUCTURE

Perform a test spray to verify proper processing.

15

Keep checking the thickness of the layer as you work.

16

✓

✓

Remember to keep an eye on the machine parameters and the raw material temperature.

FINISHING

17

OFF

Turn off the device according to the manufacturer's instructions and secure the spray gun.

18

24h

After work, ventilate the room where spraying was carried out (at least 24 hours).

19

Leave a set of documents for the system.

20

Rest after the work you've done.

BE A PROFESSIONAL IN INSULATION